

Taking the measurements and adjusting the IDC®LONGWALK HARNESSSES CORRECTLY



TAKING THE MEASUREMENTS CORRECTLY

Choosing the right size ensures complete freedom of movement and protects the dog's neck and shoulders. In order to select the correct size, it is essential to measure accurately. The girth of the dog is to be measured behind the front legs, at the widest possible point. The neck girth should be measured at the base of the neck.

If any measurement fits the next size, choose the bigger one.



PUTTING ON THE DOG HARNESS

When putting on the harness, special attention should be paid to the correct adjustment of the neck strap and the girth strap. The girth strap is adjusted correctly if you are able to slide your flat palm under the harness on the back of the dog. Make sure that the adjusting buckle on the girth strap is next to the buckle, otherwise it may cause discomfort. There should be room for four fingers behind the front legs in case of sizes L, XL, XXL, three fingers for size M and two fingers for sizes XS and S.



The neck straps are adjusted correctly if the top of the chest pad is at the sternum. The red line on the neck strap marks the adjustment limit.

CHOOSING THE CORRECT HARNESS SIZE IS ESSENTIAL IN ORDER TO ENSURE SAFE AND COMFORTABLE USE.




Attention! Choosing a wrong harness size or incorrect adjustment may result in injury or the dog sliding out of the harness. If the harness is too small, the neck strap may squeeze the neck of the dog and put pressure on the neck instead of distributing it around the chest area.

The right harness size should leave enough room near the shoulder area and the dog should be able to move its legs freely.

FREEDOM OF MOVEMENT: REINVENTED

DUOFLEX SYSTEM



The elastically attached DuoFlex® rings react to every motion of your dog making sure that your harness is always comfortable even during the longest walks.

Julius-K9® will not take any responsibility for damage arising from choosing a wrong harness size or adjusting the harness incorrectly.

STORE IN A DRY PLACE, AWAY FROM DIRECT SUNLIGHT.

CLEANING AND STORAGE

Do not machine wash. Hand wash, maximum temperature 40°C/105°F.

Wash separately.

